The Bike Shield Assembly Instruction **bikeshali**

You have just purchased the most advanced and practical motorcycle storage solution on the market. Please check "Frame Tube List" and "Bolts List" before you start assembling. Follow assembly instruction from "STEP 1" to "STEP 7" in order.

The Bike Shield carries one year warranty against manufacturing defects in materials and workmanship. The Bike Shield is supposed to be fixed on the ground using the cross plate and anchor bolts so that it prevents The Bike Shield from falling down in high winds. It is also recommended to place The Bike Shield against the wall. Under customer's responsibility, The Bike Shield has to be secured to prevent any accident caused by strong wind, heavy snow or other natural disasters. Warranty does not cover defects or damages caused by accidents, alteration, improper installation, fire, earthquake, flood, lightning, storm, and other natural disasters.

- Frame Tube List -	
C Tube: Square 15x15mm 6 pcs L Tube: Square 15x15m 1 Hole 1 Hole	I pcs 2 pcs 2 pcs (Left, Right) Tube Binding Bar
Image: Cl Tube: Square 15x15mm 2 pcs Image: Cl Tube: Square 15x15mm Image: Square 15x15mm AP Tube: Square 15x15	6 pcs mm 2pcs
I Tube: Square 15x15mm 2 Holes on same sides AO Tube: Square 25x25	A Tube: Square 25x25mm
B Tube: Square 15x15mm 2 Holes on different sides	Cross Plate
- Bolts List -	/
A Bolt Set + + + + + + + + + 10 sets Length : 35mm Plastic Washer Loose Proof Nut	D Bolt Set D Bolt Set Length : 50mm Loose Prof Nut
B Bolt Set Length : 40mm Loose Prof Nut	2 ea Rubber Bolt Cap (STEP 4 - (3),(6)) 4 ea Rubber Leg
C Bolt Set Length : 40mm Plastic Washer Nut Steel Washer Loose Prof Nut	A ea Screw Bolt Length

* During the assembly, please be careful of the sharp area like the edge of Cross Plate. Screwdriver and 10 mm (13/32 inch) spanner tools required to assemble The Bike Shield.


The Bike Shield assembly video at http://thebikeshield.com/assemblyinstruction.php

The Bike Shield has to be secured to the ground.


큐 코리아

JUEUE KOREA

Dikeshald The Bike Shield Frame assembly



^t Use rubber or wooden hammer to connect Tubes.



* All bolts should be inserted from outside to inside of The Bike Shield.


①,②Assemble A Tube with Tube Binding Bar using B Bolt Set.

(3, (4) Assemble B Tube with Tube Binding Bar using A Bolt Set.

(5) Put Cross Plate on A Tube. Cross Plate has two holes for anchor bolts, fixing to the floor.

The Bike Shield Frame assembly **_bikeshigh**





(a) Assemble three (1, 2, 3) C Tubes on the left side into Tube Binding Bar.

(b) Assemble three (1,(2),(3) C Tubes on the right side into Tube Binding Bar.


Use A Bolt Set to assemble (1), (3) C Tubes. Bolts should be inserted from **outside to inside** of The Bike Shield.

Use C Bolt Set to assemble ② C Tube. Bolts should be inserted from inside to outside of The Bike Shield.

* Do not assemble AP Tubes. AP Tubes will be assembled on the next STEP.

bikeshight The Bike Shield Cover assembly

- STEP 6 -



(a) Identify front and rear side of the cover. Cover's rear side - Look up the position of two pockets for B Tube as shown.
 (b) "FRONT" and "REAR" are stamped on each side.


① Put I Tube through pocket and connect to AP Tube with both side of I Tube.

O Put CI Tube through pocket and connect to AP Tube with both side of CI Tube.

③ Start by pulling the **front side** Large Velcro flap under the AO Tube and attaching together.

(4), (5), (6) Put each pair of C Tube through left and right side of pockets and connect with each AP Tube.

- STEP 7 -



(1), (2) Put B Tube through pockets on left and right side of cover.

(3) Assemble AP Tube with both side of the B Tube.

Pull the rear side Large Velcro flap under the rear side of AP Tube and B Tube, then attach Large Velcro flap together.
 Attach Velcro straps.

6, ⑦ Insert the Steel Cover Ring to the C Bolt Set, insert Steel Washer and fasten loose proof nut.

* Adjust tension with the front and rear Velcro flaps as well as the side Velcro straps to fit cover properly on the frame.

* You can use Padlock on the right or the left side of Tube Binding Bar.

* Padlock dimensions: http://thebikeshield.com/assemblyinstruction.php